



VEHICLE FIRE OR VEHICLE TRASH FIRE RESPONSE



DRIVER	1 SWITCH OFF ENGINE	WARNING Turn off ignition; stops fuel flow from fuel system to engine	2 PULL TO APPLY PUSH TO RELEASE PARKING BRAKE	WARNING Set the parking brake	3 OFF NO	DANGER Turn off batteries	4 	WARNING Call 911 for emergency assistance
	FIRST RESPONDER	5 	DANGER Do not spray with water if fuel system is in contact with fire	6 Minimum Perimeter 100 m 330 ft	DANGER Establish a safety perimeter of 100 meters or 330 feet	7 	DANGER Remove all ignition sources. Do not use flares near a CNG vehicle.	8 ATTENTION ATTENCIÓN CNG vent location Emplacement de l'évent de GNC Ubicación de ventilación de GNC MS24 1711, Rev. A
9 		DANGER Thermally activated pressure relief device located in fuel system	10 	DANGER Possible jet fire if thermally activated pressure relief device activates	11 	DANGER CNG fuel system leak might have a hissing sound or rotten egg smell	12 ON OFF GAS SHUT OFF VALVE	NOTICE Refer to operator manual for valve location and operations
13 Possible Jet Fire		DANGER Do not climb on top of vehicle during a fire event	14 	DANGER Do not stand under tailgate; open tailgate could fall	15 Hazard	WARNING Watch for secondary hazards	16 	WARNING Refer to operator manual before recovery or towing
<p>First Responder Card: Notify first responder and tow operator the vehicle is a CNG vehicle and status of the fuel system.</p>								



VIEW FIRST RESPONDER GUIDE

DANGER

IF FUEL SYSTEM WAS INVOLVED IN A FIRE, DEFUEL BEFORE TOWING.